

LS3 Style Coil Mount Instructions



The LS3 style coils are a popular choice amongst car enthusiasts looking to upgrade to a coil on plug system without breaking the bank. These billet brackets allow LS3 style coils to be mounted to our tried-and-true FFP Customs billet coil mounts. The kit includes all hardware to install LS3 style coils to the FFP customs coil mounts; this includes:

- 16 ¼-20 x 1-1/4 Stainless Steel Button Head Screws
- 16 ¼-20 Nylock Nuts
- 16 ¼ Washers
- 8 FFP Customs LS3 style coil mount adapters

Tools needed for this installation:

- 5/32 Hex Key
- 7/16 Wrench/ratchet

First, mount the coils to the FFP LS3 Coil mount adapters in the orientation pictured below using the ¼-20 x 1-1/4 Stainless Steel Button Head Screws, ¼-20 Nylock Nuts, and 1/4" washers.



All 8 coils will mount to the adapters in the same way. Once the coils have been mounted to the adapters, it is time to mount the coil and adapter to the FFP Coil Mounts. The hardware for this step is included with the FFP Coil Mount kits (1/4-20 x 1" Stainless Steel Button Head Screws). The orientation for the coils on the mount can be seen in the pictures below.



Figure 1 Passenger Side Coil Mount with 1 LS3 style coil mounted.



Figure 2 Passenger Side Coil Mount with 2 LS3 style coils mounted. Repeat for remaining coils.



Figure 3 Driver Side Coil Mount with 1 LS3 style coil mounted.



Figure 4 Driver Side Coil Mount with 2 LS3 style coils mounted. Repeat for remaining coils.

Like all other FFP Customs parts, these LS3 style coil adapters were designed as a Bolt On & Go installation. However, if you do hit any snags with the installation feel free to contact us via phone or social media. We would rather you contact us for clarification instead of being frustrated with the installation.

Proudly Made in the USA.

FFP Customs

(813) 928-1449

www.FFPCustoms.com

Copyright © 2021 Frazier's Fabrication & Performance. All Rights Reserved.