


2005-2014 Mustang Pedal Assembly Main Structure & Brake Pedal Instructions



FFP Customs prides itself on not only manufacturing quality parts, but also offering real world, race car solutions. Our Patented Pedal Assembly is another product aimed at improving your experience behind the wheel of your race car. These instructions are designed to make installing your new FFP Customs Pedal Assembly that much easier, so follow along as we guide you through the installation process.



Depending on the pedal assembly you have ordered, each individual pedal will be pre-assembled, as will the pedal assembly's main structure, off which everything is built. So, along with the subassemblies, and Wilwood master cylinder box, we also have hardware bags that go with the appropriate subassembly. With the main structure and brake pedal assembly we include hardware bags for the pedal pad, cowl panel mount, reservoir mount, and brake master cylinder mount, and the brake firewall mount.

First things first, we have shipped you our pedal assembly with some of the components already installed together. This has been done to lessen the intimidation one may feel when receiving a pedal assembly. With many subassemblies pre-built, we hope this makes the final installation much more understandable and easier to follow.

Pedal Assembly Contents


- Pedal Assembly main structure pre-assembled.
- Brake Pedal pre-assembled.
- Clutch Pedal, if applicable, pre-assembled.
- Throttle Pedal, if applicable.
- Pedal Pads for each included pedal.
- Brake Fluid Reservoir Mount.
- Wilwood Master Cylinder.
- Hardware Bags for each component.



The Pedal Assembly's main structure installs using the outside firewall mount and the inside firewall mount. Before you do anything, drill out the brake booster/outside firewall mount holes with a 25/64" drill bit for our hardware. Then, install the body to cowl panel mount (Left) and loosely install it (Center) to your cowl using the supplied hardware from the bag labeled "Cowl Panel Mount." Then take your outside firewall mount, feed it through the 4 holes you just drilled out, and fit the inside firewall mount and main structure to the 2 studs (top holes) and 2 bolts with the outside firewall mount. Then take the main structure's cowl panel and bolt it to the body to cowl panel mount. At this point you can tighten the nuts that attach the outside firewall mount to inside firewall mount. We suggest not tightening any of the other hardware until you have the brake pedal/master cylinder installed.

The main structure is the key to our pedal assembly. Once you have the main structure installed, the rest of the installation is a matter of adding the brake pedal and master cylinder, the throttle pedal, and if applicable, the clutch pedal.

The master cylinder bolts to the brake pedal, and then the subassembly is fitted into the main structure. Once a comfortable seating position has been attained, mark the main structure where you want to mount the brake pedal and master cylinder. The brake pedal and master cylinder will need to be removed and bench bled prior to final assembly.




Not only is the brake pedal assembly adjustable fore and aft, but you can also adjust pedal pad height, as well, thanks to the extra provisions at the bottom of the brake pedal. As mentioned, the brake pedal and master cylinder mount arrive to you in the box as a subassembly. Attach the included Wilwood master cylinder to the brake pedal subassembly and it is ready to be attached to the main structure. Make sure the pedal has freedom of movement. We include a threaded Heim joint, and shoulder bolt with lock nut to connect the master cylinder to the brake pedal at the top. The Heim joint shoulder bolt and nut needs to be arranged in this fashion to provide clearance for full brake pedal travel (Right). This is looking down at it from overhead. Make sure not to preload the master cylinder or you could cause brake drag.

With the main structure, brake pedal and master cylinder installed, do not tighten everything until you have adjusted it to your liking and bled the master cylinder. With the master cylinder bled and everything firmly attached, the brake pedal portion of the installation is done.



The main structure/brake pedal assembly includes this reservoir mount for the brake master cylinder. This mount is designed to use the roll bar running behind the dash, but if you don't have that, the reservoirs still need to be mounted above the master cylinder for proper operation as they are gravity fed.



These lines, fittings, and brake light switch are included with the pedal assembly. These fittings and lines connect the master cylinder to the bulkhead at the firewall (right). The way we have the fittings laid out here on the bulkhead, you can easily run a line for the rear brakes using the 90-degree fitting, and the other to the Line-Loc and/or front brakes. This layout is just an example of how and where to mount the bulkhead and fittings. The bottom picture is the correct layout for the fittings that screw into the master cylinder. Banjo Bolt, 9/16 ID sealing washer, -3AN Banjo, and 1/2 ID sealing washer.

If you have made it this far, you have completed the installation of the FFP Customs pedal assembly's main structure and brake pedal subassembly. If you have also ordered a throttle pedal and/or clutch pedal subassembly as part of your FFP Customs pedal assembly, we have included separate instruction sheets to also ease the installation of those subassemblies.

If you have any installation concerns or roadblocks, please call us. We would rather you call us for clarification instead of being frustrated with the installation.

Proudly Made in the USA.

FFP Customs

(813) 928-1449

www.FFPCustoms.com